

Connecting Your Scale Cable

This section will show you how to connect your Scale Cable to the Terminal.

*Note:
The Scale-to-COM Adapter should come attached to the Terminal and labeled as "Scale".*

Connection

Take the FEMALE end of the supplied 9-pin Scale Cable (LIGHT GRAY) and attach it to the MALE end of the COM Adapter (BLACK).



This connection has only one (1) orientation and simply slides into place.